

2015+ EVAP SYSTEM RETROFIT KIT **\*\*UPDATED\*\***

- STEP 1- REMOVE EVAP AIR SENSOR & EJECTOR T FITTING FROM FACTORY AIR BOX
- STEP 2- INSERT EVAP AIR SENSOR INTO T
- STEP 3- CUT EVAP HOSE AND INSERT T FITTING W/ EVAP AIR SENSOR
- STEP 4 -CONNECT PCV HOSE TO PCV PORT ON INTAKE/FILTER
- STEP 5- INSERT EJECTOR T INTO LINE COMING FROM LARGE EVAP PORT ON INTAKE UTILIZING NEW SUPPLIED HOSE
- STEP 6- RECONNECT FACTORY LINES TO EJECTOR PORT

