

TOOLS NEEDED:

- 1: PLIERS
- 2: RAZOR BLADE
- 3: 10mm Wrench
- 4: 13mm Socket & Ratchet

DIFFICULTY:

1 out 5

STEPS:

- 1: Remove Factory AirBox/Intake
- 2: Remove Battery and Battery Tray (3) 13mm Bolts
- 3: Locate Charge Pipe Port (Remove all factory lines from Intake to Charge pipe port and EVAP Port)
- 4: Cap port on Charge pipe reuse clamp from factory line on new cap
- 5: Remove factory fitting from factory hose (Fitting That slips into EVAP port)
- 6: Insert Factory Port into Silicone line
- 7: Run Silicone line to larger port on Intake
- 8: Replace Battery Tray and battery
- 9: Re-install intake/Factory Air-Box

