

This kit includes five pre-cut pieces. Installation is pretty simple, but this guide will help you.

Hoses #1-3 are all on the car's passenger side, 4 and 5 are on the driver's side.

HOSE PLACEMENT:

Hose #1: goes to the small connection on intake tube to bottom of pressure sensor.

Hose #2: to lower forward pointing fitting on pressure sensor to waste gate accuator.

Hose#3: pressure port below turbo inlet to top of pressure sensor.

Hose#4: boost pipe to evap line

Hose#5: Intake manifold to air/oil separator housing.

Once your hose kit is installed it requires no service and should last the life of your car.
To clean them use a rag lightly soaked with water and dish soap.
If they are really dirty use a rag soaked lightly with paint thinner.
This will make them look like new!

