

Tools Needed:

- 8mm Wrench
- Flattip Screw Driver
- Plastic Trimming Device (IE Dremmel)

Difficulty: 1/5

Install Time: 10min

Step 1: Remove 8mm Bolt On Factory Ram Air Port

Step 2: Use Flat tip Screw Driver to disconnect from Airbox

Step 3: Remove Ram-Air Port and Accordion section from Car

Step 4: Flip over Ram-Air Port and remove lower Clip utilizing a dremel or cutting device.

Step 5: Remove accordion section and discard.

Step 6: Install Ram Air Boot to Ram-Air Port and re-install.

Step 7: Tighten 8mm Bolt to secure Ram-Air Boot.

Step 8: Install top portion of Ram Air boot to Air Box

Step 9: Ensure fitment and tighten both SS hose Clamps

Thank you as always for your purchase!

Photos:

