



EUROCOMPULSION

V 1.0

INSTALLATION

V2.1 INTAKE SYSTEM

FIAT 500T / ABARTH MY2012-2015

EUROCOMPULSION V2 / V2.1 INTAKE SYSTEM

Tools Needed:

- 1-1/4 Ratchet with small extension
- 1-8mm socket
- 1-screwdriver
- 1-pair of pliers
- 1-pair of snips
- 1- small cup of soapy water (lubricant)

Time Needed:

20-30min

*(Make sure car is cool)

Skill Level

Level 1-5: Skill level 1

REMOVAL PROCEDURE

STEP 1- Remove the 8mm screws on the Air filter box / unclip hose from Red cover

STEP 2 – Remove Red cover and DISCARD OEM Filter (!!!OEM filter is no longer used!!!)

STEP 3 - Loosen Clamps from airbox cover and from turbo inlet

STEP 4 - Using screw driver pull Fresh Air inlet from air filter box

STEP 5 - Using pair of pliers remove small vacuum line and remove large vacuum line (pinch tab)

STEP 6 – Remove clamp from stock airbox hose to PCV valve (V2.1 Intakes please remove airbox and PCV hose from car)

INSTALL PROCEDURE

STEP 1- Install new PCV extension and filter into car (V2.1 Intakes utilize a Silicone line that runs from the Silicone intake to the PCV system, do not use OEM line)

STEP 2 – Install aluminum coupler into filter (make sure coupler is flush with inside of filter)

STEP 3- Begin installing silicone Intake hose

STEP 4 – Tighten clamp on turbo inlet

STEP 5 – Install Vacuum lines (use a bit of soapy water as lubricant for smaller line)

STEP 6- Install filter w/ coupler to Silicone Hose(use soapy water) (be careful of radiator cap)

STEP 7 – Tighten clamps / Slip PCV line behind Airbox

STEP 8- Slip (3) zip-ties through airbox retaining clips and around PCV extension hose

STEP 9 – !!!ALIGN FILTER AWAY FROM RADIATOR CAP AND OTHER ITEMS FILTER MAY RUB ON!!!

STEP 10- Once aligned tighten zip-ties (tight)

STEP 11- Install red Airbox cover (!!!!NO OEM FILTER!!!)

Congratulations Your All Finished!

Thank you for your purchase. If you have any comments or concerns please do not hesitate to contact us.

